



Rochdale 1-1/4 in (32 mm) DIA Cabinet Knob - Graphite

Part Number: A53710GPH

Rochdale Knob, 1-1/4 in (32 mm), Graphite

Fusion of architectural details and runaway flair defines utilitarian elegance in the Rochdale Collection. Rivets and masculine design aesthetics give it an industrial look.

<div>
</div>

Collection	Rochdale
Colour Group	Dark Grey
Finish Code	Graphite
Knob Diameter	32 mm
Material	Zinc Diecast
Mounting Type	8-32 Machine Screw
Projection (Height)	29 mm
Style Family	Transitional
Type	Knob

Product Description

The Amerock A53710GPH Rochdale(TM) 1-1/4in(32mm) DIA Knob is finished in Graphite. Fusion of architectural details and runaway flair defines utilitarian elegance in the Rochdale Collection. Rivets and masculine design aesthetics give it an industrial look. Elegant, rich and warm, Graphite is the perfect alternative for those who love a dark, smooth finish but prefer a hint of grey. Amerock markets decorative hardware solutions that inspire, coordinate and help express personal style. For the kitchen, bathroom and the rest of the home, with a variety of finishes and designs for all decorating tastes, Amerock is the ultimate, time-tested source for hardware needs. Amerock markets products in four categories: decorative hardware, decorative hooks, bath accessories and functional hardware.

Product Advantages

- Gorgeous, high-end finishes available
- Intricately crafted with precise detail for lifelong beauty and durability
- Amerock Guardian Lifetime Guarantee against defect in material and workmanship

Included Products

Industry standard mounting hardware



Technical Documents



INSTALLING NEW CABINET HARDWARE

Step 1. Location of Cabinet Hardware

While there are no hard, fast rules for placement of a knob or pull on a cabinet door, most cabinet makers will locate them approximately 3"-4" above the upper non-hinged corner on base cabinets, or the lower non-hinged corner on wall cabinets. However, the decision is your to make!



Step 2. Mounting Cabinet Hardware

When drilling for a knob or pull, a 3/16" hole is recommended for most styles. The exception is pulls that have "studs". A stud is simply an extension of the molded screw holes. If a pull has a stud, then a 1/4" hole is required with studs sitting securely in the wood.



IMPORTANT Screw Information

Amerock® includes 8-32 x 1" long machine screws with most knobs and pulls because the typical cabinet door or drawer front is 3/4" thick. This screw length should work in most applications. However, if your cabinet doors or drawer fronts are thicker than 3/4", then you will need to use longer screws for mounting. Check the thickness of both a cabinet door and a drawer front in your kitchen, as the thickness dimensions may not be the same. In general, the screw length(s) used should be 1/4" longer than the thickness of your cabinet door or drawer front material. It is not uncommon for some drawers to be constructed with a 3/4" thick front attached to a 3/4" thick drawer box. In this situation, the total drawer thickness is 1-1/2", making a 1-3/4" long screw necessary for mounting. These screws may be purchased from any hardware store. Please note that select hardware sold by Amerock may include metric screws instead of UNC screws.

View this product online at <https://marathonhardware.com/pd/A53710GPH>

