



Puck Light Jig Kit and Case

Part Number: TP-PLJ

Puck Light Installation Jig

Install wire and puck lights in 5/8" or 3/4" panels without using a false bottom! Includes jig body, 2-1/4" forstner guide, 2-1/4" and 2-1/8" forstner bits, 12" drill bit, and durable carrying case.

Product Description

The LED Puck Light Installation Jig Kit is everything you need to start making a profit with LED lighting. Save time and money by installing a wire and puck lights in 5/8" or 3/4" panels without using false bottoms and create a cleaner, custom look. Could also be used for strip lights, switches and concealing wires.

Product Advantages

- Revolutionary design eliminates false bottoms / cabinet build-ups
- Included drill bits cover 95% of LED puck light sizes
- Conceals wires and lights in panels as thin as 5/8"
- Can be used with puck lights and strip lights
- Forstner bits of 2 1/4" and 2 1/8" w/ depth stops are included
- Long wire drill bit - 3/8" x 12" length with stop collar is included
- Aluminum jig body with split-bushings
- Comes in durable hard plastic carrying case



Technical Documents

CABINET LIGHTING JUST GOT EASY

WITH TRUE POSITION TOOLS' PUCK LIGHT JIG



1 Clamp jig in desired location.



2 Drill light hole to desired depth using adjustable stop.



3 Leave clamps in place drill wire hole until bit reaches light hole.



4 Pull wire through.



5 Press in light!



LIFETIME WARRANTY
Bushings are backed with a lifetime warranty.

The LED Puck Light Installation Jig Kit is everything you need to start making a profit with LED lighting. Save time and money by installing a wire and puck lights in $\frac{5}{8}$ " or $\frac{3}{4}$ " panels without using false bottoms and create a cleaner, custom look.

Could also be used for strip lights, switches and concealing wires.

- Revolutionary design eliminates false bottoms / cabinet build-ups
- Included drill bits cover 95% of LED puck light sizes
- Conceals wires and lights in panels as thin as $\frac{5}{8}$ "
- Can be used with puck lights and strip lights
- Forstner bits of $2\frac{3}{4}$ " and $2\frac{3}{8}$ " w/ depth stops are included
- Long wire drill bit - $\frac{3}{8}$ " x 12" length with stop collar is included
- Aluminum jig body with split-bushings
- Comes in durable hard plastic carrying case



800 840 1228 | MARATHONHARDWARE.COM

View this product online at <https://marathonhardware.com/pd/TP-PLJ>

