



125mm

- 1

**1mm**

**3mm**

**x12**  
4.5mm

Supplied components
- Remove tray assembly from housing
- 3

19mm

18mm

16mm

**x8**

Install spacers if required
- L**

**R**

Use above template to mark holes
- x8**  
2.5mm

Drill mark holes
- x8**  
4.5mm

Mount lid
- Measure internal width of carcass and mark on inside of door
- 8

$b - c = e$

Typical **b** distances (mm)

16	18	19	24
----	----	----	----

Typical **c** distances (mm)

2	14	16	17	22
3	13	15	16	21
4	12	14	15	20
5	11	13	14	19

Measure benchtop to housing (b) and door gap (c) to calculate (e). Mark down from top of door
- L**

**R**

**x4**  
2.5mm

Align instructions and use side templates to mark and drill holes
- x4**  
4.5mm

Attach tray assembly to door
- Install tray assembly
- Adjust horizontal    Adjust vertical    Adjust forward / backward    Lock adjustments
- Install bins

125mm

17.5mm

17.5mm

17.5mm

